

Pos.No.	Description	Spare Part No.
2	Grid lid (hinge 100 mm).....	40.002
3	Mixer drum incl. mixer gate, complete set.....	40.003
3 R	Rubber strap for grid lid	40.003R
4	Frame, complete w/wheels etc.	40.004
4 A	Frame, "Body" - excl. wheels and telescopic legs	40.004A
5	Loading wheel (1 pc.), 80 mm, excl. bolt.....	40.005
5 B	Bolt (1 pc.) for 80 mm loading wheel.....	40.005B
6	Wheel (1 pc.), 300 mm, excl. bolt	40.006
6 B	Bolt (1 pc.) for 300 mm wheel.....	40.006B
6 W	Washer (1 pc.) for 300 mm wheel.....	40.006W
7	Mixer gate incl. bolt etc.....	40.007
8	Switch 9.5 Amp. w/thermal circuit breaker.....	40.008
8 E	Safety switch - by the grid lid	40.008E
8 K	Cassette for safety switch, complete.....	40.008K
8 K1	Piece for safety switch, bended metal part	40.008K1
8 K2	Piece for safety switch, twisted metal part	40.008K2
8 K3	Piece for safety switch, rubber part	40.008K3
9	Mixer arm (1 pc.), Side (long).....	40.009
9 A	Mixer arm (1 pc.), Side (short).....	40.009A
10	Mixer arm (1 pc.), Side-base.....	40.010
11	Mixer arm (1 pc.), Rake.....	40.011
12	Drive shaft, complete	40.012
12 A	Spring pins, complete set of 12 incl. a jig.....	40.012A
13	Gear motor 0.75 kW, 1400/30 RPM., 230 V.....	40.013
13 G	- Gear <i>only</i>	40.013G
13 M	- Motor <i>only</i>	40.013M
14	Starting capacitor 125 µf.....	40.014
15	Operating capacitor 25 µf.....	40.015
16	Phase capacitor 20 µf.....	40.016
17 B	Telescopic legs, rear.....	40.017B
17 L	Teleskopic leg (1 pc.), front - left side	40.017L
17 R	Teleskopic leg (1 pc.), front - right side	40.017R
17 SB	Bolt and nut (1 pair) for telescopic leg (1 pc.)	40.017SB
19	Safety grid by the mixer gate	40.019
22	Mixer arms, 4 pcs., complete set	40.022
22 A	Mixer arms, 4 pcs., wo/cross joint	40.022A
30	Discharge chute (incl. nuts).....	40.030
44	Cross joint for mixer arms, steel.....	40.044

Spare Part List - 40 L, 230V

